



Mixing ratio for Brawoliner RR, 1 and 3

Weight in KG	Base in KG	Hardener in KG
1	0,75	0,25
2	1,5	0,5
3	2,25	0,75
4	3	1
5	3,75	1,25
6	4,5	1,5
7	5,25	1,75
8	6	2
9	6,75	2,25
10	7,5	2,5

Mixing ratio for Brawoliner H T

Weight in KG	Base in KG	Hardener in KG
1	0,83	0,17
2	1,67	0,33
3	2,50	0,50
4	3,33	0,67
5	4,17	0,83
6	5,00	1,00
7	5,83	1,17
8	6,67	1,33
9	7,50	1,50
10	8,33	1,67
11	9,17	1,83
12	10,00	2,00