

# SACTOOLS CARE AND MAINTENANCE

**INDOOR  
OPTIMIZED  
EQUIPMENT**  
www.sacpro.se

**NOTE!** These instructions only apply tools with a silicone packer cover.

**OBS!** Instruktionerna gäller endast verktygen med fixturer i silikon.



## CARE AND MAINTENANCE OF SILICON PACKER COVERS

To make sure that the durability of the Packer Cover will be as long as possible, we recommend you to follow these instructions.

### BEFORE USE (THE INSIDE):

Spray siliconspray into the air connection of the Packer Cover for lubrication on the inside of the tool. One time with the connection part on the inside and one time with the connection part on the outside. (at least every fifth time)

**NOTE!** Before steam cure lubricate the tool every time.

### AFTER USE:

Clean the packer cover. If necessary, wash off with water only. Make sure that all remaining epoxy disappear.

### STORAGE:

Wrapped in plastic in a normal room temperature (+20C°).

**NOTE! CAN NOT BE USED WITH STEAM CURING IF THE TEMPERATURE IS HIGHER THAN +50C° MAX.PRESSURE 0,5 BAR**



## SKÖTSELANVISNINGAR AV GRENRÖRS-VERKTYG MED SILIKON FIXTUR

För att Grenrörsverktyget ska hålla så länge som möjligt rekommenderar vi er att följa dessa anvisningar.

### FÖRE ANVÄNDNING INVÄNDIGT:

Spraya siliconspray (vi rekommender Rivolta) in i verktygets lufthål för invändig smörjning. En gång med indragen stickledning, en gång med utsläppt stickledning.(minst var 5:e gång)

**OBS!** Vid ånghärdning smörj varje gång.


### EFTER ANVÄNDNING:

Ta bort eventuella epoxyrester. Torka av vertyget. Vid behov tvätta av med endast vatten.

### FÖRVARING:

Inlindad i plast i rumstemperatur.

**OBS! MAXIMAL TEMPERATUR I VERKTYGET VID ÅNGHÄRDNING +50C°. MAXTRYCK 0,5 BAR**



**NOTE!** PARTS OF THE PACKER COVER THAT IS NOT COVERED BY THE FEED BRANCH PIPE, MUST NOT BE PRESSURIZED (INSTALLED) WITHOUT BEING PROTECTED IF IT IS IN THE OPEN AIR, OUTSIDE A PIPE. PROTECT THE EXPOSED PART OF THE PACKER COVER WITH A PEACE OF CALIBRATION HOSE, PIPE OR OTHER.

**OBS!** DE DELAR AV FIXTUREN SOM INTE TÄCKS AV FODERGRENRÖRET, FÅR INTE SÄTTAS UNDER TRYCK (INSTALLERAS) UTAN ATT SKYDDAS OM DET LIGGER I FRIA LUFTEN, DVS UTANFÖR ETT RÖR. SKYDDA DEN UTSATTA DELEN AV FIXTUREN MED EN BIT KALIBRERINGSSLANG, RÖR ELLER ANNAT.