


INSTRUCTIONS CARE AND MAINTENANCE FOR PACKER COVERS WITH A SILICONE SURFACE (DUAL LAYER)

**INDOOR
OPTIMIZED
EQUIPMENT**
www.sacpro.se



NOTE! These instructions only apply to tools with a packer cover that has a multi-layer material with a silicone surface.

OBS! Instruktionerna gäller endast verktygen med fixturer som har ett flerskiktmaterial med en silikonyta



CARE AND MAINTENANCE OF PACKER COVERS WITH A SURFACE OF SILICON

To ensure longest possible durability of the packer cover, we recommend you to read, and follow these instructions.

BEFORE USE (THE INSIDE):

Spray silicone spray into the air connection of the packer holder to lubricate the inside of the packer cover (we do recommend Rivolta). Repeat procedure as often as necessary (approx. every 5 sets when ambient cured or between every set when steam/hot cured).

AFTER USE:

Clean the packer cover. Use water if necessary, to make sure that you get rid of all remaining epoxy residue.

STORAGE:

At normal room temperature (+20°C) wrapped in plastic or in the plastic tubes that follow the packer holder.

NOTE! THE ADDED TEMPERATURE MUST NOT BE GREATER THAN +50°C. THE MAXIMUM PRESSURE IS 0,5 BAR.



SKÖTSELANVISNINGAR AV GRENRÖRS-VERKTYG MED EN SILKONBASERAD YTA

För att Grenrörsfixturen ska hålla så länge som möjligt, rekommenderar vi er att följa dessa anvisningar.

FÖRE ANVÄNDNING INVÄNDIGT:

Spraya silikonspray (vi rekommenderar Rivolta) in i fixturhållarens luftanslutning för att minska friktionen invändigt i verktyget. Upprepa detta vid behov (ca var 5:e gång vid kallhärdning, eller varje gång vid ånghärdning).


EFTER ANVÄNDNING:

Tag bort eventuella epoxirester. Vid behov kan vatten användas.

FÖRVARING:

Inlindad i plast i rumstemperatur.

OBS! MAX TILLFÖRD TEMPERATUR +50°C. MAXTRYCK 0,5 BAR.



NOTE! Parts of the packer cover that is not covered by the feed branch pipe, must not be pressurized (installed) without being protected if it is in the open air, outside a pipe or there is another connection in the pipe to close the installation. Protect the exposed part of the packer cover with a piece of calibration hose, pipe or equivalent.

OBS! De delar av fixturen som inte täcks av fodergrenröret, får inte sättas under tryck (installeras) utan att skyddas om det ligger i fria luften, dvs utanför ett rör eller ett annat grenstick ansluter för nära installationen. Skydda utsatta delen av fixturen med en bit kalibreringsslang, rör eller annat.